



PART NUMBER

PFF32-408

DESCRIPTION

FRONT UPPER WISHBONE BUSH

INSTALLATION GUIDE

Product description:

This part replaces OE number: RBX500443 to suit cast steel arms found on the Range Rover Sport (2005-2013), for pressed steel arms use PFF32-406 and PFF32-407.

Contents (parts per pack):

- 4 x Polyurethane A bushes
- 4 x Polyurethane B bushes
- 4 x Stainless steel sleeves
- 1 x Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original rubber bushes from the front upper wishbone, clean any dirt and corrosion from its bores.
2. Fit the polyurethane A bush into the bore of the wishbone from the outside face of the wishbone.
3. Fit the polyurethane B bush into the bore of the wishbone from the inside face of the wishbone.
4. Apply some of the supplied grease to the bore of the bush and insert the sleeve into the bush.
5. Re-fit the wishbone to the car and tension all hardware to manufacturers recommended torque settings.

