

INSTALLATION GUIDE

Contents (parts per pack):

1 x bush 1 x Stainless steel sleeve 1 x Plain Washer
1 x Washer A 1x Washer B 1x Shake proof washer 1 x Grease

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*

All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original rear diff front bush from the subframe. Clean any rust and dirt from the hole.
2. Push the new bush into the subframe, the end with recessed facing outwards away from the diff.
3. Apply some of the supplied grease to the bore of the bush, push the stainless steel sleeve into the bush. The slotted hole helps to align the bolt hole. Fig A.
4. Refit the supplied new plain washer that sits between the diff and bush. Fig A.
5. Fit washer "A" with slotted hole into the recess on the outer face of the bush, Again using the slotted hole to help to line up the bolt hole.
6. Place washer "B" and shake proof washer onto original bolt, refit and tighten. Fig B.
7. Tension all hardware to manufacturers recommended torque settings.



Fig A



Plain washer

Washer A

Washer B

Shake proof washer

Fig B