



**PFR57-507**  
**Porsche 911 (996)**  
**Rear Lower Link Arm Inner**  
**Bush**

Remove the original bush from the alloy arm. Clean out any dirt and corrosion. Fit the 2 Polyurethane parts into the arm, coat the stainless steel sleeve with the grease supplied and slide it into the bushes, the sleeve will protrude out both ends. Place the supplied steel D shaped washers over the protruding sleeve after coating it in the grease. Place arm back into sub frame with the flat of the washer pointing inwards so bush misses raised casting when making tracking adjustments. Replace Bolt make tracking adjustments as necessary, retighten bolt. Make sure flat of washer is correctly positioned when future adjustments are made to allow full adjustment.



**PFR57-507**  
**Porsche 911 (996)**  
**Rear Lower Link Arm Inner**  
**Bush**

Remove the original bush from the alloy arm. Clean out any dirt and corrosion. Fit the 2 Polyurethane parts into the arm, coat the stainless steel sleeve with the grease supplied and slide it into the bushes, the sleeve will protrude out both ends. Place the supplied steel D shaped washers over the protruding sleeve after coating it in the grease. Place arm back into sub frame with the flat of the washer pointing inwards so bush misses raised casting when making tracking adjustments. Replace Bolt make tracking adjustments as necessary, retighten bolt. Make sure flat of washer is correctly positioned when future adjustments are made to allow full adjustment.

