

PART NUMBER

## PFR76-614

DESCRIPTION

REAR UPPER ARM FRONT BUSH

### INSTALLATION GUIDE

#### Product description:

This part fits OEM part number 48770A, 48790.

#### Contents (parts per pack):

2 x A bushes      2 x B bushes      2 x stainless steel sleeve  
1 x Grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
  - all safety precautions adhered to;
  - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

#### Fitting Instructions:

1. Remove the original front bush from the arm. Fig A.
2. Clean any dirt and corrosion from the bore of the arm.
3. Insert 'A' bush with bigger top hat into the bore from the front of the car. Insert 'B' bush with smaller top hat into the bore towards the rear of the car. Fig B.
4. Apply some of the supplied grease into the bore of the bush, push the stainless steel inner sleeve into the bush.
5. Re-fit arm to the car. Tension all hardware to manufacturers recommended torque settings.



Fig A.



Fig B.