

POWERFLEX®

PART NUMBER

PFR25-430

DESCRIPTION

Rear Shock Absorber Top Mounting Bush

INSTALLATION GUIDE

Contents (parts per pack):

4 x Polyurethane Bushes

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Jack up the rear of the vehicle, and support with axle stands.
2. Loosen the lower shock absorber bolt.
3. Access, loosen and remove the shock absorber top mounting nut, and remove the washer and upper bush.
4. Holding the shock absorber steady, remove the lower bolt and then remove the shock absorber from it's upper mounting.
5. Remove the old lower bush from the top mounting of the shock absorber
6. Wirebrush the outside of the sleeve on the piston of the shock absorber, removing any corrosion and sharp edges. Do not attempt to remove the sleeve from the piston, as this will permanently damage the threads.
7. Fit one of the Powerflex bushes with the taper facing towards the bottom of the shock absorber.
8. Re-mount the shock absorber to the upper mounting point on the car, and fit the lower mounting bolt.
9. Push the other Powerflex bush to the top of the sleeve, with the taper facing upwards. Re-fit the factory washer and nut and tighten all fixings to factory torque specifications.

